

Warning: Before starting, please carefully read the instructions and, if possible, lower the blinds.

When the upper limit is going to be set customer must be careful to stop the blinds when the top slat is near the headrail, since the motor has no limits set yet the blind will continue to go up and motor will snap the cords if it's not stopped on time.

Note: a "Jog" is a small up/down movement of the blind

1.-Reset Motor.

– Press and Hold P1 button until your blind makes 4 jogs and release, you will hear 4 beeps.

2. Pair Control.

2.1 - Select the desired Channel on the remote.

2.2 - Press and hold the P1 button on the blind motor for 2 to 3 seconds and release (the blind should do 1 jog and a long beep sound). **Step 2.3 must be done within 8 seconds of this one.**

2.3 - On the remote press and hold the stop button for 2 jogs (3-4 seconds) and release (you will get 3 quick beeps meaning the control has been paired).

3. Change Tilt orientation.

check current orientation first (if pressing the up arrow moves the blind down orientation must be changed)

To change orientation:

- On the remote hold the up and down arrow at the same time until you get 1 jog and release.

4.Set Upper Limit. (be careful on this step if the blind is not stopped on time it can snap the cords)

-Press and hold the UP Arrow for 2 seconds, blind will start moving up.

-Press Stop at the desired limit (or when the top slat is near the headrail).

-Once blind has stopped, Press and hold the "UP arrow" and "Stop button" at the same time until you get 2 jogs and release. (you will hear 3 beeps, upper limit has been set).

5.Set Lower Limit.

-Press and hold DOWN Arrow for 2 seconds, blind will start moving down.

-Press Stop when the blind is fully down or at the desired limit.

-Press and hold DOWN arrow and Stop at the same time until you get 2 jogs and release (you will hear 3 beeps; lower limit has been set).

6. Activate Tilting.

- At the same time press and Hold the UP and Down arrows until you get 1 jog and release as soon as the blinds moves.

-Hold Stop button until you get 1 jog and release.

-you will hear a beep; tilt has been activated.

Blinds is now fully programmed.

