


---

## MOTORIZED OPEN ROLL SHADES IDLE END WITH LOCKING TAB Installation Instructions

---


The locking tab prevents the release dial from rotating and adds security at the bracket.

1. Before installing the shade:
  - Ensure the idle end pin is fully extended
  - Confirm the locking tab is in the locked DOWN position
  - Verify the release dial is locked and cannot rotate




*Note: the locking tab is shown in red for demonstration purposes. The production version will be white.*

**LOCKED**



**When LOCKED, the locking tab sits flush with the idle end collar.**

**UNLOCKED**



**When UNLOCKED, the locking tab extends above the idle end collar.**

2. To install, push in the pin on the idle end of the shade and move the shade up so that the pin engages with the hole in the idle end bracket.

**IMPORTANT!** The locking tab must remain locked while the shade is installed and operated.


3. To uninstall, lower the shade to access the locking tab and to protect the fabric. Then, lift the locking tab up to unlock. Fully raise the shade, then turn the release dial to remove the shade from the bracket.



*View video  
instructions here*

# LOCKING TAB INSTRUCTIONS

Idle end locking tab prevents release dial from rotating and keeps shades securely mounted.



## LOCK

To install the shade:  
Ensure tab is  
locked in the DOWN  
position, then push  
the idle end pin in  
and install into the  
bracket.

## UNLOCK

To uninstall the  
shade: Lift tab  
UP to unlock and  
rotate dial.



## IMPORTANT!

Tab **MUST REMAIN  
LOCKED** while shade  
is installed and  
operated.

*View video  
instructions here*