


Einbauanleitung für Sicherheitseinrichtung

Installation instruction for safety device

Installatie instructie voor veiligheidsinrichting

BG - Монта́ж инструкци́е за устройст́во безопа́сност
CZ - Instalační instrukce pro bezpečnostní zařízení
DK - Installations vejledning til sikkerhedsanordning
ESP - Instrucciones de instalación para el dispositivo de seguridad
EST - Paigaldusjuhend ohutusseadde
F/B - Les instructions d'installation pour le dispositif de sécurité
FIN - Asennusohje turvalaitte
GR - Οδηγίες εγκατάστασης για τη συσκευή ασφαλείας
H - Szerelési útmutató biztonsági berendezés
HR - Upute za sigurnost uređaja za ugradnju
IT - Istruzioni per l'installazione di dispositivo di sicurezza

LT - Uzstādīšanas instrukciju drošības ierīci
LV - Instrukcija dėl saugos įtaisas
N - Monteringsanvisning for sikkerhedsanordning
NL/B - Installeatie instructie voor veiligheidsinrichting
PL - Instrukcja instalacji dla urządzeń zabezpieczających
PT - Instruções de instalação para o dispositivo de segurança
RO - Instrucțiunile de instalare pentru dispozitiv de siguranță
S - Installationsanvisning för säkerhetsanordning
SK - Inštaláčne inštrukcie pre bezpečnostné zariadenia
SLO - Navodila za montažo za varnostne naprave



⚠ WARNING

The CSD18 Safety device is a fixed tensioning device for operating ball-chains that form a continuous loop. This device must be applied in chain loops that do not have a breakaway design. The safety device prevents free-hanging loops in operating chains. Install the safety device at the maximum distance possible from the control mechanism, this shall prevent that the loop becomes slack. Upon delivery to the end user, the device must be attached to the chain.

Designed for ball-chains of $\varnothing 4.5\text{mm}$ in diameter.

The child safety device is delivered without fasteners.

Please check your local legislation for correct delivery to the end consumer.

